

Maintenance Instructions

All maintenance is subject to use and conditions of use. A regular routine of maintenance is required to keep your Flooring looking its best and performing to its design.

REGULAR MAINTENANCE

- Remove all loose dirt by sweeping or vacuuming.
- Damp mop floor using a neutral pH cleaner such as our Neutral Cleaner. Follow manufacturer's directions for mixing and using.
- When mopping the floor, DO NOT FLOOD THE FLOOR WITH WATER. This can cause the adhesive to break down and the floor to loosen.
- If desired and/or as needed, use a LOW speed buffer with white pads to scrub floor with a neutral pH cleaner. DO NOT use a high speed buffer as this will damage the floor.

PREVENTATIVE FLOOR CARE

- Properly place protective floor matting at any entrance to remove loose dirt and moisture from shoes.
- Maintain a steady routine of cleaning to keep dirt and dust off the floor in order for it to look and perform its best
- Clean up any spills as they occur.
- Floor protectors should be used on all furniture legs.

SPECIAL NOTES

WearGUARD is an aluminum oxide wear layer that seals the surface of the Flooring improving hygiene and chemical resistance. This eliminates the need for floor finishes, however, you may add a finish such as our Flooring's Matte or Gloss Finish to change the visual appearance of the floor.